

American Safe Room Register Duct Connection Kit



**Drawing: ASR-50-RDK
Revision: C
December 6, 2016**

Table of Contents

Introduction 3
Installation 3
Parts drawing 4

Introduction

This kit allows you to quickly connect your Safe Cell to a floor register duct commonly found in commercial and residential construction and pull air from your HVAC system into your NBC filter. It will cover up to a 6 by 12 inch register. The register is not included.

Installation:

1. The cover plate is positioned over the register.
2. The J bolt is inserted down through the register and rotated to hook one of the louvres.
3. The clamp bar is placed over the other end of the J bolt.
4. The wing nut is tightened down on the threaded end of the J hook.
5. The intake hose is slipped onto the top of the cover plate.

Refer to the parts drawing on the following page to identify these parts.



Parts drawing

